




ASSEMBLY INSTRUCTIONS--WPD6





HELP LINE
0800 0126777





i Information
if in doubt contact the supplier


 Please read these instructions thoroughly before commencing assembly.


 Inspect all packages for damage and check that all components have been supplied


 Assembly should be undertaken by at least two people


 **Caution**
During Assembly


 Wear appropriate clothing -protective gloves and footwear are recommended


 Dispose of packaging materials responsibly


 Make sure the floor is level


 Allow adequate working space and be aware of others working around you


 Take care when handling heavy items particularly when lifting or stretching

 **Warning**
Rules for safe use of shelving

 Not suitable for use in damp or wet environments.

 ENSURE THAT THE MAXIMUM LOAD CARRYING CAPACITIES ARE NOT EXCEEDED

 Shelves must be loaded evenly and load heavier items on the bottom shelves

 Never climb or stand on the shelves.


TOOLS REQUIRED



RUBBER Mallet

Assembly instructions-WPD6

- 1** Select two uprights **A** and push on plastic feet **D** to the bases. Insert a short side beam **C** into the keyholes at the lowest shelf level required.



- 2** Tap beam **C** with a rubber mallet to ensure the end studs are fully located in the bottom of the keyholes on both uprights. Lean the uprights **A** against a wall for support if needed



- 3** Repeat steps 1 and 2 until you have created a "ladder style frame"

Tip: Now is a good time to check the space between beams suits the items you want to store on the shelves and adjust as required




- 4** Select two more uprights **A** and repeat steps 1 to 3 until you have a second "ladder style frame"

Tip: Use the first frame as a template to get the correct spacing



- 5** Take two long beams **B** and insert them into the keyholes on one frame at the same height as the short beams. Tap into place with a rubber mallet




- 6** Insert the other ends of the beams **B** into the second frame as in step 5



- 7** Repeat steps 5 and 6 to add the remaining long beams. Ensure that each long beam is located at the same height as the side beams



- 8** Locate 1 support beam **F** onto the metal studs on each long beam **B**. Tap into place and repeat for all levels



- 9** Insert chipboard decks **E**

